EASTMAN®
WOODPECKER®

Model WPP
Reciprocating Cutter

Operation Manual

⚠ CAUTION
Machine Equipped With Sharp Blade

⚠ WARNING
Safety glasses must be worn at all times when operating or servicing this equipment.

Your new Woodpecker is designed to replace hand held shears for increased performance and capacity with a minimum of maintenance and service. Equipped with either a 30° angle tip blade for thick material or 45° angle tip blade for thin material.

Replacement Blades	
80C13-65	30°angle tip blade (Thick material)
80C13-66	45°angle tip blade (Thin material)



TO OPERATE MACHINE

Connect Air Supply to machine (60-90psi). Lay fabric over soft foam to protect the blade. Place Woodpecker on material and press lever #2 to begin cutting.

To Adjust Blade Speed (1,000 -55,000 stroke per minute)
Adjust knob #1 clockwise to decrease speed and counter-clockwise to increase speed.

To Replace Blade
Remove (2) screws and replace blade #3 as required.

To Adjust Blade Angle
Loosen knob #4 and adjust blade mount for desired blade angle.

To Adjust Blade Height (0 - 5mm (.20 in.))
Loosen top lock ring and adjust lower ring #6 as required.

To Adjust Handle Height
Loosen screws #7 and adjust height as required.

779 Washington St., Buffalo, N.Y. 14203-1396 U.S.A. • (716)856-2200 • Fax (716)856-1140 or (716)856-2068
Manufacturers of Eastman Cloth Cutting and Cloth Spreading Machines
Website: WWW.EastmanCuts.com

Form C-1596



SAVE THESE INSTRUCTIONS

⚠ **WARNING:** When using air tools, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury, including the following:

READ ALL INSTRUCTIONS

WORK AREA

- Keep your work area clean and well lit. Cluttered and dark work areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools may create sparks which may ignite the dust or fumes.

PERSONAL SAFETY

- Stay alert, watch what you are doing and use common sense when operating the Woodpecker. Do not use tool while under the influence of drugs, alcohol, or medication. A moment of inattention while operating may result in serious personal injury.
- Dress properly, Do not wear loose clothing or jewelry. Contain long hair. Keep you hair, clothing and gloves away from moving parts. Loose clothing, jewelry, or long hair can be caught in moving parts.
- Avoid accidental starting. Be sure switch is in locked or off position before connecting air supply. Carrying tools with you finger on the switch invites accidents.
- Use safety equipment. Always wear eye protection and dust mask for appropriate conditions.

TOOL CARE

- Do not force tool. Use the correct tool for your application.
- Disconnect air supply from tool before making any adjustments, changing accessories, or storing the tool. Such preventative safety measures reduce the risk of starting the tool accidentally.
- Maintain tools with care. Keep the blade sharp and clean. Properly maintained tools with sharp cutting edges are less likely to bind and are easier to control.
- Use only Eastman accessories with your Woodpecker. Accessories that may be suitable for one tool may create a risk of injury when used with another.

SERVICE

- Tool service must be performed only be qualified repair personnel.
- When servicing a tool, use only Genuine Eastman replacement parts.

Limited Warranty. Eastman warrants to the buyer that the Woodpecker shall be free from defects in materials or workmanship for a period of 6 months commencing on the date of invoice. Any goods or parts claimed by the buyer to be defective must be returned to Eastman, freight charges prepaid, within the 6 month warranty period. If Eastman determines that the goods or parts are defective in materials or workmanship, Eastman's sole obligation under this warranty shall be, at Eastman's sole option, to repair or replace the defective goods or parts or to provide to the buyer a credit equal to the portion of the purchase price allocable to the defective goods or parts. This warranty shall not apply if defects are caused by product misuse or neglect, if the machine has been altered or modified by the buyer, or if other than genuine Eastman belts, emery wheels, knives or parts are used in the machine. THIS WARRANTY IS THE ONLY WARRANTY APPLICABLE TO THIS PURCHASE. SELLER DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Limitation of Liability. Eastman's liability to the buyer, and the buyer's remedies from Eastman, whether in contract, negligence, tort, under any warranty or otherwise, shall be limited to the remedies provided in the foregoing Limited Warranty. In no event shall Eastman have any responsibility or liability to the buyer for (a) any special, indirect, incidental, or consequential damages, including, but not limited to, loss of use, revenue, or profit, even if Eastman has been advised of the possibility of such damages, or (b) any claim against the buyer by any third party. The price stated for the product sold is a consideration for limiting Eastman's liability.

Eastman®
Over a Century of Cutting Expertise

779 Washington St., Buffalo, N.Y. 14203-1396 U.S.A. • (716)856-2200 • Fax (716)856-1140 or (716)856-2068
Manufacturers of Eastman Cloth Cutting and Cloth Spreading Machines
Website: WWW.EastmanCuts.com

Form C-1596
©2005 Eastman Machine Company
Printed in U.S.A. 8/05